
Density Gradient Column Filler

Operating Manual



Document version 5.02

Firmware version 5.03

H & D Fitzgerald Ltd.

www.density.co.uk

Copyright 2018, H&D Fitzgerald Ltd. Tremeirchion United Kingdom.

All rights reserved. Reproduction in whole or in part is prohibited without the written consent of the copyright holder.

For any comments, suggestions, request, or queries about this product, contact:

H&D Fitzgerald Ltd.

Cefn Du

Tremeirchion

St Asaph

Denbighshire

LL17 0US

United Kingdom

www.density.co.uk

email: admin@density.co.uk

tel: +44 (0)1352 720774

Contents

1	Introduction	1
	1.1 Equipment supplied as standard	1
	1.2 Equipment also available	1
2	Warnings and safety precautions	2
3	Density gradient column techniques	3
	3.1 Choice of liquids	3
	3.2 Hints for filling the column	5
	3.3 Sample preparation	6
	3.4 Introducing samples to the column	6
	3.5 Determining when samples have come to rest	6
	3.6 Extending the life of your gradient column	7
	3.7 Temperature control.....	8
4	Preparing the column filler for use	9
	4.1 Description of the parts	9
	4.2 Operating conditions	10
	4.3 Fitting the tubing and column filler tubing configuration	11
	4.4 Switching the filler on and shutting down.....	14
	4.5 Entering the volume of the tubing	15
5	Filling the column	18
	5.1 Setting the column parameters	18
	5.2 Calibrating the pumps	22
	5.3 To fill the column.....	29
6	Calibrating the column	34
7	Measuring the density of a sample	39
8	Using a sweeper	42
9	Care and maintenance	47
	9.1 Cleaning	47
	9.2 Replacing the pump tubing.....	47
	9.3 Repairs	47
10	Filling example	48
	10.1 Water and sodium bromide solution	48
11	Specification	49
A	Shrinkage in 2-propanol / water mixtures	50
B	Preparing a 2-propanol / water column - worked example using pre-mixed solutions	52

